



User's Manual

Version: 3.0
Date: April. 15, 2013

Table of Contents

1	Overview	5
2	Package Contents	7
3	USB Token Contents	8
4	Physical Details	9
5	AirStick	12
6	What You Might Need	13
7	Quick Installation	14
8	WiPG-1500 Receiver Device	16
8.1	PC-List	16
8.2	Setup Page	17
8.3	Remote Touch Control (UST/UoIP).....	18
8.4	Whiteboard	18
8.5	Pen drawing	19
9	DoWiFi for Windows.....	20
9.1	Install the application.....	20
9.2	Start the application	21
9.3	Quick Connect.....	22
9.4	Connect to WiFi Network	22
9.5	Connect to Receiver Device	23
9.6	Login.....	23
9.7	Main User Interface	24
9.8	Screen Projection.....	24
9.9	Audio Projection	25
9.10	Menu	25
9.10.1	Show Receiver Information.....	26
9.10.2	Web Admin.....	26
9.10.3	Search Receiver Device	26
9.10.4	Launch SidePad	27
9.10.5	Enable WebSlides.....	28
9.10.6	Select Projection Desktop	28
9.10.7	Projection Quality	29

Table of Contents










9.10.8	Select Projection Mode.....	29
9.10.9	Resolution Settings	29
9.10.10	Projection Aspect Ratio	29
9.10.11	Enable USB IWB Bridge	30
9.10.12	Advanced Screen Capture	30
9.10.13	Send Audio to Display.....	31
9.10.14	Auto Power Manager.....	31
9.10.15	Auto WiFi Connect.....	31
9.10.16	Make wePresent WiPG-1500 Token	32
9.10.17	Copy Application to desktop.....	33
9.10.18	Hot Key	33
9.10.19	About.....	33
9.10.20	Exit.....	33
10	DoWiFi for Mac.....	34
10.1	Install the application.....	34
10.2	Start the application	34
10.3	Quick Connect.....	35
10.4	Connect to WiFi Network	35
10.5	Connect to Receiver Device	36
10.6	Login.....	37
10.7	Main User Interface	37
10.8	Screen Projection.....	38
10.9	Audio Projection	38
10.10	Menu	39
10.10.1	Show Receiver Information.....	40
10.10.2	Web Admin.....	40
10.10.3	Search Receiver Device	40
10.10.4	Launch SidePad	40
10.10.5	Enable WebSlides.....	41
10.10.6	Select Projection Desktop	41
10.10.7	Projection Quality.....	42

Table of Contents

10.10.8	Select Projection Mode.....	42
10.10.9	Resolution setting.....	42
10.10.10	Projection Aspect Ratio	43
10.10.11	Send Audio to Display.....	43
10.10.12	Auto WiFi Connect.....	43
10.10.13	Hot Key	43
10.10.14	About.....	44
10.10.15	Exit.....	44
11	Web Management.....	45
11.1	Home Page.....	45
11.2	Download	46
11.3	Conference Control	46
11.4	WebSlides	47
11.5	Admin.....	48
11.5.1	System Status.....	49
11.5.2	Device Setup.....	50
11.5.3	System Status	50
11.5.4	OSD Setup	54
11.5.5	Change Passwords.....	54
11.5.6	Reset to Default	55
11.5.7	Firmware Upgrade.....	56
11.5.8	WebSlides Setup	57
11.5.9	Reboot System.....	58
11.5.10	Logout.....	58
12	Appendix	59
12.1	Wall-mount Instructions.....	59

wePresent WiPG-1500 is professional wireless presentation gateway. By enabling the Revolutionary “interactive” and “UST/UoIP” functions, you can throw your presentations wirelessly from a PC, Mac, iPad, iPhone, or Android devices to a projector, and use the touch screen/IWB, mobile phone or Pad to control the presentation remotely.

» WiPG-1500 Features Highlight:

Icon	Feature	Description
	DoWiFi	Wireless Display-over-WiFi for Windows and Mac
	WiFi-Doc	High quality presentation via iPhone/iPad or Android devices (Word, Excel, PPT,PDF , Photo , Screenshot)
	SidePad	Control the presentation on PC or Mac via iPhone/iPad or Android devices
	WebSlides	Broadcast slides to your devices with WiFi and web browser
	AirStick	Advanced 3D presentation controller
	Drawing / Whiteboard	Free drawing on projecting content or interactive whiteboard
	4-to-1 projection	Project four PC/Mac screens to one projector at once.
	Conference Control / PC-List	Control projection from WiPG's web page, or use mouse/ keyboard to select a PC from the standby screen.
	SNMP V3	Manage WiPG devices across the corporate network through enhanced SNMP V3 protocol


- ## Basic Features

- High performance screen/audio projection for Windows/Mac (Windows8 and Mac Mountain Lion)
- Remote desktop control from USB AirStick, Touch Screen or Mouse/Keyboard for Windows/Mac
- Plug&Show: launching the projection application from a USB thumb drive without installation
- High performance 4-to-1 Quadrant Screen Projection
- Support up to 64 concurrent login users
- Conference Control: Mediator function through the device web page or standby screen
- Support Wireless Multi-touch control (Win7/8 standard HID compatible device)
- Support drawing feature for projecting sender screen, or drawing on whiteboard without PC
- SNMP V3: manage/configure multiple WiPGs through SNMP V3 protocol
- Security design: Session Login Code, WEP/WPA/WPA-Enterprise WiFi Security, and GateKeeper
- HDMI and VGA dual video interfaces
- WiFi AP and AP-Client mode support
- WiFi 802.11b/g/n information

Package Contents

2

- wePresent WiPG-1500 Box
- wePresent WiPG-1500 USB Token
- Power Adapter (DC +5V, 2.5A)
- 2 WiFi Antenna
- AirStick
- Quick Installation Guide
- Wall Mount Kit
- Warranty Card




USB Token Contents

3


-
- Windows Installer (WiPG-1500 Windows Installer)
 - MAC Installer (WiPG-1500 Mac Installer)
 - VAC Driver (For Windows XP Audio Projection)
 - VDD Driver (For Windows XP/Vista Virtual Extended Screen)
 - USBolP Driver (For USB IWB Bridge)
 - Utility
 - PtG Converter (For MobiShow PtG function)
 - SNMP Manager (For SNMP Management)

- Front Panel




	Description
Power Button and LED	Power on/off button. LED Indicator: System Loading(Red), Ready(Yellow)
USB Port (Front)	USB port for USB mouse and keyboard

- Rear Panel




	Description
Antenna	WiFi Antenna
USB Port (Rear)	USB port for USB IWB device (HID type)
RJ-45	10/100M RJ-45 port
VGA Connector	VGA connector
HDMI	HDMI Connector
Audio Jack	Audio Jack (3.5mm)
Power Jack	Power Jack (5V/2.5A)

- Bottom Side



	Description
Screw Hole	Screw Hole for Wall Mount Kit
Reset Button	Press reset button and power on the device to execute Hardware Reset.

AirStick USB device is wireless remote controller. It can control the WiPG-1500 device and projecting PC/Mac remotely.




What You Might Need

-
- Projector or HDTV with VGA/HDMI interface
 - Windows or Mac PC/Laptop
 - Apple iPhone, iPad or iPod-touch device
 - Android Phone or Tablet device
 - Speaker (Optional, for audio projection feature)
 - USB Mouse and Keyboard (Optional, for remote desktop feature)
 - USB HID Touch Screen/IWB Device (Optional, for UST or IWB over IP feature)

Quick Installation

7

1. Connect wePresent WiPG-1500 device to Projector through VGA/HDMI port and turn on projector power.



2. Connect the power adaptor to WiPG-1500 device and press the power button to turn on WiPG-1500 device.
 - It will show the default standby screen as below when system is ready.



3. Attach the speaker cable to WiPG-1500 phone jack for audio output
4. Attach the USB mouse and keyboard to WiPG-1500 front USB port for OSD control and remote desktop control
5. Attach the USB IWB/Touch Screen cable to WiPG-1500 rear USB port for UST/IWB remote touch control

8.1 PC-List

- 1. If there are sender connected to WiPG-1500 device, it will show the available PC-List on standby screen, conference moderator can use the USB mouse/keyboard/ Touch Screen/IWB to select the PC and control it remotely.



- You can also click the feature Icon to browse the Quick Guide for each highlight feature.



8.2 Setup Page

Click the **“Setup”** icon, you can find the FW version, resolution and WiFi security information. Meanwhile, you can also calibrate the attached Touch Screen/IWB screen coordination by **“Calibration”** function.




8.3 Remote Touch Control (UST/UoIP)

WiPG-1500 can support standard Win7/8 compatible HID touch device. By attaching the HID touch screen/IWB device, you can operate the standby screen, White Board feature and the projecting PC/mobile remotely from the Touch Screen/IWB device.


8.4 Whiteboard

Click on the “**Whiteboard**” button to enable the virtual Whiteboard feature, you can make the free drawing on device screen through USB AirStick, Mouse, Touch Screen or IWB device.




8.5 Pen drawing

When user are projecting through Windows, Mac, Android and iOS sender application, you can use the AirStick/Mouse/IWB/Touch Screen to enable the Pen feature and add free drawing on top of projecting screen.



9.1 Install the application


1. Make sure your PC WiFi is enabled already, and connect your PC to wePresent WiPG-1500 box through WiFi.



2. Open your browser and enter the Device Host Name (SSID) or IP address in the browser. You can find the IP address and Host Name (SSID) on the projector screen.

(Default Host Name (SSID) is WiPG-1500, Default IP is 192.168.100.10)

3. Download the client software for “Windows 8 /7 /Vista /XP” and install on your PC.
(Ps. You can also launch the application from PnS token directly.)



4. Launch WiPG-1500 client and connect to WiPG-1500 receiver.
(Make sure you have connected to WiPG-1500 and your PC's personal firewall allows wePresent WiPG-1500 software to pass through.)


9.2 Start the application

1. Click wePresent WiPG-1500 icon on desktop to execute the application, or launch the application from PnS token directly.
2. It will start to search wePresent WiPG-1500 receiver automatically.



9.3 Quick Connect


1. WiPG-1500 will memorize the last successful connection profile and open the quick connect dialog, you can enter the code and press the “Connect” button to connect this WiPG-1500 directly.



2. If you want to connect to another WiPG-1500 receiver, please press the “Rescan” button.

9.4 Connect to WiFi Network


1. WiPG-1500 application will search the available WiFi Network and list the WiPG-1500 WiFi Device. You can select a network and press the “Connect” button to connect the selected WiFi Device.



2. You can press the “Refresh” button to search again or press the “All” button to list all available WiFi Network name.
3. If you don’t like to change the WiFi Network and keep the connection to current network, you can press the “Skip” button.

9.5 Connect to Receiver Device

1. WiPG-1500 application will search and list the WiPG-1500 receiver Device. You can select the target receiver device and press "OK" button to connect the selected receiver device.



2. You can press the "Refresh" button to search again.
3. If you can't find the target receiver device from the list, you can press the "Manual" button to enter the receiver IP address manually and connect.


9.6 Login

1. When it connects to a "Code" protection enabled WiPG-1500 receiver, you have to enter the "Code" and press the "Connect" button to login the receiver.
(You can find the CODE from the right-upper of OSD standby screen)



2. If you want to connect to another receiver or cancel the login, please press the "Cancel" button.









9.7 Main User Interface



9.8 Screen Projection

Click the **“Play”** button for full or “1,2,3,4” for split screen projection, you can project the main screen on to the display immediately. Click the **“Pause”** button, you can freeze you projection screen, and click the **“Stop”** button to stop projecting your screen.



Button	Description
	Full Screen projection
	Project to Split #1
	Project to Split #2
	Project to Split #3
	Project to Split #4
	Stop projecting
	Pause projecting
	Magnifier function


9.9 Audio Projection

1. When you are doing the full screen projection or project to split #1 screen, you can also choose to project the audio to WiPG-1500 receiver for the multimedia or video scenario.
2. To enable or disable the audio projection feature, please change the setting from WiPG-1500 menu. (Menu -> Send audio to display)

Note: For Windows XP system, please install the Audio driver ("VAC.exe", Virtual Audio Control Driver) on your computer first, you can find the software from USB Token. (Windows Vista and Win7 is not necessary to install VAC)

9.10 Menu

Press "**Menu**" button from the main UI, you will find the menu to enable the additional feature or to change the application options.



Item	Description
Show Receiver Information	Show Receiver Information on screen
Web Admin	Open web admin page
Search Receiver	Connect to another receiver device
Launch SidePad	Launch SidePad sender
Enable WebSlides	Enable WebSlides
Select Projection Desktop	Select the projection desktop
Projection Quality	Change projection quality
Projection Mode	Change the presentation or video mode.
Resolution Setting	Change the resolution setting
Projection Aspect Ratio	Change the projection screen aspect ratio
Enable IWB USB Bridge	Enable IWB USB bridge
Advanced Screen Capture	Enable advance screen capture
Send Audio to Display	Enable audio projection
Auto Power Management	Enable Auto Power management feature
Auto WiFi Connect	Enable Auto WiFi connect feature
Make Plug&Show Token	Make Plug&Show USB token
Copy Application to Desktop	Copy the application to desktop
Hot Key	Hot Key Settings
About	About this application
Exit	Exit the application

9.10.1 Show Receiver Information

Click **“Show Receiver Information”**, it will display the Receiver Information, such as WiFi Name, IP Address and code on the upper of desktop, and it will close automatically after 30 seconds.

9.10.2 Web Admin

Click **“Web Admin”**, it will open the browser and connect to the receiver web admin page automatically. (You can find the details of web admin page from another chapter.)

9.10.3 Search Receiver Device


Click **“Search Receiver Device”**, it will disconnect from current receiver and search the receiver again.

9.10.4 Launch SidePad

1. Open the main menu of the WiPG-1500 application(Win/Mac), and choose the item, "Launch SidePad"

Note: You have to download the "SidePad receiver" on your Android/iOS device, and then connect the Android/iOS to WiPG-1500 device through WiFi and Launch "SidePad receiver".

2. In seconds, you shall see the PC desktop shown on the Android/iOS Device. Use two fingers to pinch or one finger to pan the desktop image and control it by single or double clicks!



9.10.5 Enable WebSlides


Click the **“Enable WebSlides”**, it will start to broadcast your slides to the browser on connected mobile devices.

Note: Audience need to connect to WiPG-1500 WiFi Network, open the browser and click the **“WebSlides”** button to start receiving the slides.



9.10.6 Select Projection Desktop

Click the **“Select Projection Source”**, you can select to project the main screen of desktop or the extended screen.




Note: For Windows XP system, you need to install **“VDD.exe”** driver first, you can find it from USB token.

For Windows 7/Vista Starter edition, it can't support extended screen.


9.10.7 Projection Quality

Click the **“Projection Quality”**, choose **“Normal”** for faster projection speed with lower screen image quality, and **“Best”** for clear screen image quality but slower projection speed.




9.10.8 Select Projection Mode

Click the **“Select Projection Mode”**, choose the **Presentation mode** for shortest latency or the **Video mode** for auto-latency control to have better video performance.



9.10.9 Resolution Settings

Click the **“Resolution Setting”**, choose **“Never Change”** to keep original desktop resolution, **“Always Change”** to change resolution automatically according to application’s recommendation, or **“Always ask me”** to prompt a resolution change message to user.



9.10.10 Projection Aspect Ratio

Click the **“Projection Aspect Ratio”**, choose **“Keep aspect ratio”** to keep the original aspect ratio if the desktop resolution is different from WiPG-1500 output resolution, or choose **“Fit full screen”** to project the screen to full screen.



9.10.11 Enable USB IWB Bridge

1. Click the **“Enable USB IWB Bridge”**, it will enable the USB IWB Bridge feature.
2. When you start the full screen projection, it will bridge the IWB device to your PC wirelessly.

Note: You have to install the USBolP driver first. You can find the driver from USB token.

9.10.12 Advanced Screen Capture

Click the **“Advanced Screen Capture”**, you will be able to see tip windows and other layered windows (include the main UI) on the connected display. However, the mouse cursor may blink from time to time when you are projecting your PC screen!

- Disable “Advanced Screen Capture”.



- Enable “Advanced Screen Capture”.




9.10.13 Send Audio to Display

Click **“Send Audio to Display”** to start the audio projection feature. It will mute your local speaker during the projection and restore it when it closes the application.

Note: For Windows XP system, you have to install the Audio driver. (VAC.exe) You can find the driver from USB token.

9.10.14 Auto Power Manager

To make the highest projection performance, application will turn the PC’s windows power scheme from current settings to “highest performance”, however, you can click the “Auto Power Manage” to enable or disable this function and restore you power scheme immediately.





9.10.15 Auto WiFi Connect

Click **“Auto WiFi Connect”** to enable the WiPG-1500 WiFi connect feature.

9.10.16 Make wePresent WiPG-1500 Token

Click **“Make wePresent WiPG-1500 Token”** to make a USB wePresent WiPG-1500 Token, you can insert a USB thumb drive and follows the wizard to make the Token.




9.10.17 Copy Application to desktop

Click the **“Copy Application to desktop”**, it will copy the application to your desktop immediately even you don't have the system privilege

9.10.18 Hot Key

Click **“Hot Key”** to display the available Hot Key definition.



9.10.19 About

Click **“About”** to show system information. It includes product model name, Client version, IP address and other information.



9.10.20 Exit


Click **“Exit”** to exit this application. It will stop current playing status and close the application immediate.

10.1 Install the application

1. Make sure your PC WiFi is enabled already, and connect your PC to wePresent WiPG-1500 box through WiFi.
2. Open your browser and enter the Device Host Name (SSID) or IP address on browser. You can find the IP address and Host Name (SSID) on the projector screen.

(Default Host Name (SSID) is WiPG-1500, Default IP is 192.168.100.10)

3. Download the client software for "Mac" and install on your PC.
(Ps. You can also launch the application from PnS token directly.)




4. Launch WiPG-1500 client and connect to WiPG-1500 receiver.

10.2 Start the application

1. Click wePresent WiPG-1500 from Application folder to execute the application.
2. It will start to search wePresent WiPG-1500 receiver automatically.

10.3 Quick Connect

1. WiPG-1500 will memorize the last successful connection profile and open the quick connect dialog, you can enter the code and press the “Connect” button to connect this WiPG-1500 directly.



2. If you want to connect to another WiPG-1500 receiver, please press the “Rescan” button.

10.4 Connect to WiFi Network

1. WiPG-1500 will search the available WiFi Network and list the WiPG-1500 WiFi Device. You can select a network and press the “Connect” button to connect the selected WiFi Device.



2. You can press the “Refresh” button to search again or press the “All” button to list all available WiFi Network name.
3. If you don’t like to change the WiFi Network and keep the connection to current network, you can press the “Skip” button.

10.5 Connect to Receiver Device

1. WiPG-1500 will search and list the WiPG-1500 receiver Device. You can select the target receiver device and press the “Connect” button to connect the selected receiver device.



2. You can press the “Refresh” button to search again.
3. If you can’t find the target receiver device from the list, you can press the “Manual” button to enter the receiver IP address manually and connect.

10.6 Login


1. When it connects to a “Code” protection enabled WiPG-1500 receiver, you have to enter the “Code” and press the “Connect” button to login the receiver.

(You can find the CODE from the right-upper of OSD standby screen)



2. If you want to connect to another receiver or cancel the login, please press the “Cancel” button.









10.7 Main User Interface



10.8 Screen Projection

1. Click the **“Play”** button for full or split screen, you can project the main screen on to the display immediately, click the **“Pause”** button, you can freeze you projection screen, and click the **“Stop”** button to stop projecting your screen.



Button	Description
	Full Screen projection
	Project to Split #1
	Project to Split #2
	Project to Split #3
	Project to Split #4
	Stop projecting
	Pause projecting
	Enable the Mac Magnifier function


10.9 Audio Projection

1. When you are doing the full screen projection, you can also choose to project the audio to WiPG-1500 receiver for the multimedia or video scenario.
2. To enable or disable the audio projection feature, please change the setting from WiPG-1500 menu. (Menu -> Send audio to display)

Note: Please install the SoundFlower on your computer first, you can find the software from USB Token.

10.10 Menu

Press “**Menu**” button from the main UI, you will find the menu to enable the additional feature or to change the application options.



Item	Description
Show Receiver Information	Show Receiver Information on screen
Web Admin	Open web admin page
Search Receiver Device	Connect to another receiver device
Launch SidePad	Launch SidePad sender
Enable WebSlides	Enable WebSlides
Select Projection Desktop	Select the projection desktop
Projection Quality	Change projection quality
Projection Mode	Change the presentation or video mode.
Resolution Setting	Change the resolution setting
Projection Aspect Ratio	Change the projection screen aspect ratio
Send Audio to Display	Enable audio projection
Auto WiFi Connect	Enable Auto WiFi connect feature
Hot Key	Hot Key Settings
About	About this application
Exit	Exit the application

10.10.1 Show Receiver Information

Click **“Show Receiver Information”**, it will display the Receiver Information, such as WiFi Name, IP Address and code.

10.10.2 Web Admin

Click **“Web Admin”**, it will open the browser and connect to the receiver web admin page automatically.

(You can find the details of web admin page from another chapter.)

10.10.3 Search Receiver Device


Click **“Search Receiver Device”**, it will disconnect from current receiver and search the receiver again.

10.10.4 Launch SidePad

1. Open the main menu of the WiPG-1500 application(Win/Mac), and choose the item, “Launch SidePad”.

Note: You have to download the “SidePad Receiver” on your Android/iOS device, then connect the Android/iOS to WiPG-1500 device through WiFi and Launch “SidePad Receiver”.

2. In seconds, you shall see the PC desktop shown on the Android/iOS Device. Use two fingers to pinch or one finger to pan the desktop image and control it by single or double clicks!







10.10.5 Enable WebSlides

Click the **“Enable WebSlides”**, it will start to broadcast your slides to the browser on connected mobile devices.

Note: Audience need to connect to WiPG-1500 WiFi Network, open the browser and click the **“WebSlides”** button to start receiving the slides.




10.10.6 Select Projection Desktop

Click the **“Select Projection Source”**, you can select to project the main screen of desktop or the extended screen.

Note: It can only support Mac 10.7 and 10.8, to use the extended screen, you have to install the extended screen driver that provided in the USB Token.


10.10.7 Projection Quality

Click the **“Projection Quality”**, choose **“Normal”** for faster projection speed with lower screen image quality, and **“Best”** for clear screen image quality but slower projection speed.




10.10.8 Select Projection Mode

Click the **“Select Projection Mode”**, choose the **Presentation mode** for shortest latency or the **Video mode** for auto-latency control to have better video performance.




10.10.9 Resolution setting

Click the **“Resolution Setting”**, choose **“Never Change”** to keep original desktop resolution, **“Always Change”** to change resolution automatically according to application’s recommendation, or **“Always ask me”** to prompt a resolution change message to user.



10.10.10 Projection Aspect Ratio

Click the **“Projection Aspect Ratio”**, choose **“Keep aspect ratio”** to keep the original aspect ratio if the desktop resolution is different from WiPG-1500 output resolution, or choose **“Fit full screen”** to project the screen to full screen.



10.10.11 Send Audio to Display

Click **“Send Audio to Display”** to start the audio projection feature. It will mute your local speaker during the projection and restore it when it closes the application.


Note: You have to install the SoundFlower Audio driver. You can find the driver from USB token.

10.10.12 Auto WiFi Connect

Click **“Auto WiFi Connect”** to enable the WiFi connect feature through WiPG-1500 application.

10.10.13 Hot Key

Click **“Hot Key”** to display the available Hot Key definition.



10.10.14 About

Click **“About”** to show system information. It includes product model name, Client version, IP address and other information.



10.10.15 Exit

Click **“Exit”** to exit this application. It will stop current playing status and close the application immediate.

11.1 Home Page


1. Make sure your PC connect to wePresent WiPG-1500 box successfully.
2. Enter the receiver IP address on browser; you can find the IP address on the projector screen.(Default IP is 192.168.100.10)



11.2 Download

1. Select “**Download**” function.
2. Please select the “Win 8 / 7 / Windows Vista /XP” or “Mac Utility” and execute the installation program.

Note: Please disable the “Smart Screen Filter” on IE browser; otherwise you might not able to download the file.









11.3 Conference Control

1. Select “**Conference Control**” function, it will show current connected sender list.
2. Enter password and then press [**Login**]. (Default password: moderator)




3. After login, you can see a User List on the screen which indicates all of users connected to WEPRESENT WiPG-1500 box.
4. There are three columns, “Computer Name”, “Play Control” and “IP Address”.

5. Play Control, There are six buttons, including Play(Full) , Play Split #1 , Play Split #2 , Play Split #3 , Play Split #4  and Stop .
6. Uncheck the “Allow Control from this page only”, it will disable the centralized control and user can project the screen to WiPG-1500 freely.




11.4 WebSlides

1. Press the “WebSlides” button to enter the WebSlides page.
2. Enter the password if necessary. (Default password: disabled)
3. Start to receive the projecting slides.



11.5 Admin

Click [**Admin**] and then enter the password to login web admin page. (Default Password: admin)



11.5.1 System Status

Click [**System Status**], it will show current system status.

Model Name: Product model name

Versions:

- **Firmware version no.:** Product firmware version number.

Network Status:

- **IP address :** IP address of WiPG-1500 device.
- **Subnet Mask :** subnet mask
- **Default Gateway :** default gateway
- **Wireless MAC address :** wireless MAC address
- **Wire MAC address :** wire MAC address

Connection Status:

- **Projecting status :** “Waiting for projecting” or “Projecting”
- **Total Users :** It shows how many users login to wePresent WiPG-1500.
- **Code :** It will show current Code

wePresent

wePresent-WiPG > Admin > System Status Logout »

System Status	Model Name	WiPG-1500
Device Setup	Versions	
Network Setup	Firmware Version	1.0.0.0
OSD Setup	Network Status	
WebSlides Setup	IP Address	192.168.168.70
Change Passwords	Subnet Mask	255.255.255.0
Reset to Default	Default Gateway	192.168.168.251
Firmware Upgrade	Wireless MAC Address	00:12:5F:08:43:62
Reboot System	Wire MAC Address	00:12:5F:01:75:7C
	Connection Status	
	Projecting Status	Waiting for Projecting
	Total Users	0
	Code	8648

Copyright © 2013. All Rights Reserved


11.5.2 Device Setup

Click [**Device Setup**] button, it will show the device setting items,

Choose <**VGA**> or <**HDMI**> output option

<**Resolution**>:

- **HDMI:** 720p, 1080i, 1080p
- **VGA:** UXGA(1600*1200), WXGA+(1440*900), WXGA(1360*768, 1280x768, 1280x800), XGA(1024*768), and SVGA(800*600). The default value is XGA(1024*768).
- <**Code**>: You can select "Disable", "Random", or "Use the following code" to set a specified 4-characters Number.
- <**IWB USB Port**>: You can configure the IWB USB port to support "IWB (HID)" device or "Mouse/Keyboard" device
- <**Apply**>: Confirmation and Save modifications
- <**Cancel**>: Cancel all the modifications



11.5.3 Network Setup

Click [**Network Setup**] button, it will show the network setting items,

(Note: Auto-Configuration Network Setup on WiPG-1500)

The default setting of the wePresent WiPG-1500 box is DHCP client. When the wePresent WiPG-1500 box is connected to a LAN that already has a DHCP server present, the wePresent WiPG-1500 box takes an IP address assigned to it by the server. When the wePresent WiPG-1500 box is connected to a LAN that does not have a DHCP server, the wePresent WiPG-1500 box becomes the DHCP server in the network.

<**IP Setup**>

- You can select “obtain IP address automatically” or “Use the following IP address”
- **IP Address:** The default value is 192.168.100.10.
- **Subnet Mask:** The default value is 255.255.255.0
- **Default Gateway:** The default value is 192.168.100.10
- **DNS Server:** The default value is 192.168.100.10

<DHCP Server Setup>

- You can select “auto(Enable/Disable DHCP Server” or “Disable”)
- **Start IP:** The start IP address of DHCP Server.
- **End IP:** The end IP address of DHCP Server
- **Subnet Mask:** The default value is 255.255.255.0
- **Default Gateway:** The default value is 192.168.100.10
- **DNS Server:** The default value is 192.168.100.10

< Wireless Setup>

- **Wireless LAN:** The default value is “Enable”
- **SSID:** SSID string, max. Length is 32 bytes.
- **SSID Broadcast:** The default value is “Enable”
- **Channel:** to set fixed channel or Auto. The “Auto” means after power on wePresent WiPG-1500, it will scan all of wireless channel and select clear one channel automatically.
- **Encryption:** you can select “Disable” or one of WEP/WPA/WPA2 64bit or 128bit in ASCII or HEX string.
- **Key:** If Encryption is enabled, you have to set key value according to the encryption mode you selected.
- **Channel Bandwidth:** select from 20M or Auto (40M/20M)

< AP Client>

- **Connect to Existing AP:** Input the SSID of Home WiFi AP you want to connect.
- **Encryption:** you can select “Disable” or one of WEP/WPA/WPA2 64bit or 128bit in ASCII or HEX string.
- **Key:** If Encryption is enabled, you have to set key value according to the encryption mode you selected.
- Press Apply button, and follow the reboot instruction to make it work.

< Host Name and Domain Name>

- **Host Name:** It will use the same name as SSID for the device host name
- **Domain Name:** You can also enter the domain name of this device if there is DNS server available.

< Gatekeeper>

Gatekeeper is designed for ensuring the enterprise network security within wePresent WiPG-1500 box

- All Block can block Guest Users(through wireless) to access all office network(LAN),
- All Allow can pass Guest Users(through wireless) to access all office network
- Internet Only can block Guest Users (through wireless) from office network (LAN) but still reserve internet connection capability.


< SNMP V3>

- Enable or disable SNMP service
- **User Name:** configure the user name to manage this device through SNMP
- **Auth Password:** configure the Auth password
- **Priv Password:** configure the Priv password
- **Trap IP:** configure the trap receiver IP

<Apply >: press button to select this mode.

<Cancel>: press button to abort action.

<Back>: Back to Operating mode main menu.

- System Status
- Device Setup
- Network Setup
- OSD Setup
- WebSlides Setup
- Change Passwords
- Reset to Default
- Firmware Upgrade
-  Reboot System

IP Setup	<input checked="" type="radio"/> Obtain an IP address automatically <input type="radio"/> Use the following IP address	
	IP Address	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="10"/>
	Subnet Mask	<input type="text" value="255"/> <input type="text" value="255"/> <input type="text" value="255"/> <input type="text" value="0"/>
	Default Gateway	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="10"/>
	DNS Server	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="10"/>
DHCP Server Setup	<input checked="" type="radio"/> Auto <input type="radio"/> Disable	
	Start IP	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="11"/>
	End IP	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="254"/>
	Subnet Mask	<input type="text" value="255"/> <input type="text" value="255"/> <input type="text" value="255"/> <input type="text" value="0"/>
	Default Gateway	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="10"/>
	DNS Server	<input type="text" value="192"/> <input type="text" value="168"/> <input type="text" value="100"/> <input type="text" value="10"/>
Wireless Setup	Wireless LAN <input checked="" type="radio"/> Enable <input type="radio"/> Disable	
	SSID	<input type="text" value="WiPG-1500"/>
	SSID Broadcast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	Channel	<input type="text" value="Auto"/>
	Encryption	<input type="text" value="Disable"/>
	Key	<input type="text"/> <input checked="" type="checkbox"/> Hide characters
	Channel Bandwidth	<input type="radio"/> 20MHz <input checked="" type="radio"/> Auto
Ap Client	Connect to Existing AP <input type="radio"/> Enable <input checked="" type="radio"/> Disable	Existing AP SSID <input type="text"/> <input type="button" value="Scan"/>
	Encryption	<input type="text" value="Disable"/>
	Key	<input type="text"/> <input checked="" type="checkbox"/> Hide characters
Host Name and Domain Name	Host Name(SSID)	<input type="text" value="WiPG-1500"/>
	Domain Name	<input type="text"/>
GateKeeper	<input checked="" type="radio"/> All Pass <input type="radio"/> All Block <input type="radio"/> Internet Only	
SNMP V3	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
	User Name	<input type="text" value="Admin"/>
	Auth Password (MD5)	<input type="text" value="....."/> <input checked="" type="checkbox"/> Hide characters
	Priv Password (DES)	<input type="text" value="....."/> <input checked="" type="checkbox"/> Hide characters
	Trap	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>

Apply Cancel

11.5.4 OSD Setup

Click [**OSD Setup**] button, you can change the standby Logo image

Change Standby Image

- **Replace Logo Image:** Replace logo image only.
- **Replace entire standby image:** Replace the whole standby image
- **<Reset to default>:** Restore to default Logo image.
- **<Image File Upload>:** Upload the customized Logo Image.

Display Option

- **Device Info:** Show or Hide the device info.
- **Font Size:** Change the font size of display info.
- **Screen Saver Settings:** Enable or disable the screen saver and also configure the idle interval. (default is 5 mins)

wePresent

wePresent-WiPG > Admin > OSD Setup Logout »

System Status
Device Setup
Network Setup
OSD Setup
WebSlides Setup
Change Passwords
Reset to Default
Firmware Upgrade

Change Standby Image

Type: Replace Logo Image
 Replace entire standby Image (PC-List feature will be disabled)

Image Name: Default

Restore to default

File Name:

Image File Upload

The image file need to be PNG format and the maximum file size is 510K.
(Recommended image resolution Logo: 1200*300, Standby image: 1280*720)

Display Option

Device Information: Show All Hide All

Font Size: Normal Large

Screen Saver Settings: Enable Disable

Idle Time (Minutes): 5

Apply Cancel

Copyright © 2013. All Rights Reserved

11.5.5 Change Passwords

Click [**Change Password**] button, you can change the password setting.

(Length: up to 8 characters)

- **<Enter New Password>:** enter new password you want to change for each category.
- **<Confirm New Password>:** Confirm the new password again.
- **<Apply>:** Confirm and Save modifications.




11.5.6 Reset to Default

Click [**Reset to Default**] button to restore factory default settings.

<**Apply**>: Confirm and take action.


*** To execute the Hardware Factory Reset to Default, Please follow below procedures.

1. Press [Reset] button and Hold.
2. Turn on wePresent WiPG-1500 box.
3. Wait for over 10 seconds and relief [Reset] button.
4. It will take effect to restore factory default settings.



11.5.7 Firmware Upgrade

1. Click [**Firmware Upgrade**] button to import/export system configuration and upgrade firmware.
2. System Configuration Import and Export
3. Export: Export the system configuration to a configuration file
4. Import: Import the system configuration file to WiPG-1500
5. Firmware Upgrade
 - a. Firstly, you have to get latest firmware image file from your vendor.
 - b. Click <Browse> to specify file name you want to upgrade.
 - c. Click <Upgrade> to start.
 - d. A warning message shown and count down counter on the screen.
 - e. After a few minutes, a complete message shown on the screen.
 - f. Restart wePresent WiPG-1500 box to take effect.



The screenshot shows the wePresent web interface. The top navigation bar includes the wePresent logo and the breadcrumb path: wePresent-WiPG > Admin > Firmware Upgrade. A Logout button is visible in the top right. On the left, a sidebar menu lists various system management options: System Status, Device Setup, Network Setup, OSD Setup, WebSlides Setup, Change Passwords, Reset to Default, Firmware Upgrade (highlighted), and Reboot System. The main content area is titled 'System Configuration' and contains several sections: 'Export System configuration' with an 'Export' button and a file selection field; 'Import' with an 'Import' button and a file selection field; 'Firmware Version' (1.0.0.0) and 'Release Date' (20130313); a warning message: 'Please stop the projection function first before you apply the Upgrade button!!'; and 'File Name' with an 'Upgrade' button and a file selection field. The footer of the page reads 'Copyright © 2013. All Rights Reserved'.




Please wait while System burns new firmware into your device.

Warning: It needs to take 10~15 minutes to burn the file you transferred into flash memory. **During this period, any interrupt such as shut down or reboot the system will cause system crash!!**

Estimated Time remaining: : 890seconds



 **Warning:** Don't power off wePresent WiPG-1500 while firmware upgrade in progress, otherwise will cause your Box doesn't work and have to return device to your vendor for fixing.

11.5.8 WebSlides Setup

1. Click [**WebSlides Setup**] button to setup the WebSlides Feature.
2. Auto Refresh Interval: choose "Manual Refresh", "10", "20", "30", "45", "60" and "90" seconds
3. Access Password Control: choose "Disable", "Use the same password as Code" or "Use the following Code"

A screenshot of the wePresent web management interface. The top header shows the "wePresent" logo and navigation links: "wePresent-WiPG > Admin > WebSlides Setup" and a "Logout" button. A left sidebar contains a menu with items: "System Status", "Device Setup", "Network Setup", "OSD Setup", "WebSlides Setup" (highlighted), "Change Passwords", "Reset to Default", "Firmware Upgrade", and "Reboot System". The main content area is divided into two sections: "Auto Refresh Interval (second)" with radio buttons for "Manual Refresh" (selected), "10", "20", "30", "45", "60", and "90", each with a note about recommended concurrent users; and "Access Password Control" with radio buttons for "Disable", "Use the same password as 'Code'" (selected), and "Use the following Code:" followed by a text input field and "(0-9)". Below these sections is a "Note" about network connectivity for more than 10 users, and "Apply" and "Cancel" buttons. The footer contains the text "Copyright © 2013. All Rights Reserved".

11.5.9 Reboot System

Click [**Reboot System**] button, you can restart the system


- <**Reboot**>: reboot system automatically.



The screenshot shows the wePresent Admin interface. The breadcrumb navigation is "wePresent-WiPG > Admin > Reboot System". A "Logout" button is in the top right. The left sidebar contains a menu with "Reboot System" highlighted. The main content area features a yellow warning icon and the text "Reboot System" followed by "This will reboot the device immediately." Below this is a "Reboot" button. The footer contains "Copyright © 2013. All Rights Reserved".

11.5.10 Logout

Click [**Reboot System**] button, you can logout the WiPG-1500



The screenshot shows the wePresent Admin interface. The breadcrumb navigation is "wePresent-WiPG > Admin > System Status". A "Logout" button is in the top right, highlighted with a red box. The left sidebar contains a menu with "Reboot System" highlighted. The main content area displays system information in a table format:

Model Name	WiPG-1500
Versions	
Firmware Version	1.0.0.0
Network Status	
IP Address	192.168.168.70
Subnet Mask	255.255.255.0
Default Gateway	192.168.168.251
Wireless MAC Address	00:12:5F:08:43:62
Wire MAC Address	00:12:5F:01:75:7C
Connection Status	
Projecting Status	Waiting for Projecting
Total Users	0
Code	8648

The footer contains "Copyright © 2013. All Rights Reserved".

12.1 Wall-mount Instructions

