


GL2800


DUAL STEREO RETURN
STEREO GAIN
ST1
DIRECT TO LR
ST2
AUX 1
AUX 2
AUX 9-10
MUTE
PFL
M
L-R
1-2
ST1-2
ST3
ST4
3-4
ST3-4
EXT IN
GRP 1
GRP 2
GRP 3
GRP 4
GRP 5
GRP 6
GRP 7
GRP 8
L
R
M
LEVEL
MTX 1
MTX 2
MTX 3
MTX 4
TALKBACK MIC
TALKBACK
MIN
MAX
OSC/NOISE
PINK NOISE
1kHz OSC
ON
M
L-R
MTX1-2
MTX3-4
AUX 1-2
AUX 3-4
AUX 5-8
AUX 9-10
LATCH
TALK
PHONES
2TRK REPLAY
2TRK TO LR
POWER
L
R
PFL/AFL
MONITOR
M
L-R
2TRK
MTX1
STEREO
MTX2
MTX3
MTX4
AUX 9-10
MONITOR
AUX 1
AUX 2
AUX 3
AUX 4
AUX 5
AUX 6
AUX 7
AUX 8
AFL
REV
AUX 9-10
STEREO
MUTE
ROTARIES
AUX MODE
FOH
MONITOR
FADERS
L-R TO M
0dB
MUTE GROUPS
M1
M2
M3
M4
M
P/AFL
WEDGE MODE
GRP1 TO M
GRP2 TO M
GRP3 TO M
GRP4 TO M
GRP5 TO M
GRP6 TO M
GRP7 TO M
GRP8 TO M
GRP1 TO LR
GRP2 TO LR
GRP3 TO LR
GRP4 TO LR
GRP5 TO LR
GRP6 TO LR
GRP7 TO LR
GRP8 TO LR
PAN
PK!
+6
0
SIG
MUTE
AFL
GRP1
GRP2
GRP3
GRP4
GRP5
GRP6
GRP7
GRP8
AUX1
AUX2
AUX3
AUX4
AUX5
AUX6
AUX7
AUX8
L
R
M
AUX8-10
LISTEN
10
5
0
5
10
20
30
00
1
2
3
4
5
6
7
8
L
R
M


+48V
POLARITY
LINE
(PAD)
GAIN
HPF
100Hz
STEREO GAIN
HF
12k
3k
1k
700
500Hz
15k
4k
6k
HM
180
70
250
45
400
35Hz
2k5
LM
250Hz
LF
80Hz
EQ IN
AUX 1
AUX 2
PRE-EQ
AUX 3
AUX 4
POST
PRE
AUX 5
AUX 6
AUX 7
AUX 8
AUX 9-10
STEREO
PAN
BAL
L
R
ODD
EVEN
MUTE
PFL
PK!
+6
0
SIG
M
L-R
1-2
3-4
5-6
7-8
M1
M2
M3
M4


+48V
POLARITY
LINE
(PAD)
GAIN
HPF
100Hz
HF
12k
HM
500Hz
LM
35Hz
LF
80Hz
EQ IN
AUX 1
AUX 2
PRE-EQ
AUX 3
AUX 4
POST
PRE
AUX 5
AUX 6
AUX 7
AUX 8
AUX 9-10
STEREO
PAN
L
R
ODD
EVEN
MUTE
PFL
PKI
+6
0
SIG
M
L-R
1-2
3-4
5-6
7-8
M1
M2
M3
M4