

Hitachi Projector Accessories

Reference Guide



Lenses

For CPX10000/CPWX11000/CPSX12000



For CPX505/X605/X608/X615/WX625/SX635/X705/X807/X809



Lamps: Business Projectors

■ Portable
 ■ Multi Purpose
 ■ Installation

<p>DT01141</p> <ul style="list-style-type: none"> • CPX7 • CPX8 • CPX4 • CPWX8 	<p>DT00821</p> <ul style="list-style-type: none"> • CPX3 • CPX5 • CPX264 	<p>DT00781</p> <ul style="list-style-type: none"> • CPX1 • CPX2 • CPX4 • CPRX70 	<p>DT00701</p> <ul style="list-style-type: none"> • CPRS55 • CPRS56 • CPRX60 • CPRX61 • CPRS57
<p>DT01181</p> <ul style="list-style-type: none"> • CPAW250NM • CPA300NM • EDA220NM 	<p>DT01171</p> <ul style="list-style-type: none"> • CPX4021N • CPX5021N • CPWX4021N 	<p>DT01151</p> <ul style="list-style-type: none"> • CPRX79 • EDX26 	<p>DT01141</p> <ul style="list-style-type: none"> • CPX2520 • CPX3020 • EDX50 • EDX52