
Antenna Combiners and Accessories

The supplied antennas can be connected directly to the BNC-type ANTENNA connectors. However, optional antenna mounting accessories from Shure can improve reception and reduce rack clutter. Use the following guidelines:


- Antennas and receivers must be from the same band.
- Mount antennas more than 40 cm (16 inches) apart.
- Use Shure UA825 or UA850 low-loss coaxial antenna cable (or any 50 ohm, low-loss cable such as RG-8U).

Visit www.shure.com for more information on wireless antenna accessories.




UA802
UA806
UA825
UA850
UA100

Coaxial Cables




UA600
Front Mount Antenna Kit




UA820
1/2-Wave Antenna
included with ULXP4 systems




UA830
Inline Antenna Amplifier
for long antenna cable runs



UA440
Antenna Rack Mount Kit




UA870
Active Directional Antenna
for more focused reception




UA844
Distribution Amplifier
combines antennas and power supplies for multiple receivers

Rack Installation

ULXP4




ULXP4 DUAL



Rackmount Options

The following shows rackmounting options for one to four receivers and lists the required accessories.



1 x UA506
1 x UA600
2 x UA820

1 x UA440
1 x UA507
4 x UA820

1 x UA844
1 x UA507
4 x UA506

1 x UA844
2 x UA507