Hitachi Projector Accessories

EDA101/111/100, CPA100

TT100
Table Top Kit (for EDA100/110/CPA100)





A1MOUNTS001
Wall Mount / Boom
- Short 60 - 80" Screen
(for EDA101/111/100/CPA100)
Item not shown, e-mail
pj.support@hitachi-eu.com
to find out more

A1MOUNTL001
Wall Mount / Boom - Long 100"
Screen (for EDA101/111/100,
CPA100)
Item not shown, e-mail
pj.support@hitachi-eu.com
to find out more

WIRELESS CARD/USB





VA08331
Wireless SD Card for Reception
All Wireless Models

USB-WL-11N
USB Wireless Adapter for
C18 WN, M2B WN models

PROJECTOR CABLE COVER

EZ01661
Cable for CPX608W

CC10000
Cable Cover

CCAW100
Direct Cable Cover

Items not shown, e-mail pj.support@hitachi-eu.com
to find out more

CONTROL BOX

CTRL001
Control Box for Projectors

Items not shown, e-mail pj.support@hitachi-eu.com
to find out more